









A1: Unpacking Your Signal Safes

Before use, check the battery power by pressing the On/Off button once for each unit. The charge level will be displayed for 3 seconds before moving into operational mode. Refer to the Charge Guide below to evaluate usage time - if insufficient, charge your product.

CHARGE GUIDE

-  **8 Hours** (continuous use)
Three blinking arrows
-  **6 Hours** (continuous use)
Three arrows
-  **4 Hours** (continuous use)
Two arrows
-  **2 Hours** (continuous use)
One arrow
-  **1 Hour** (continuous use)
Five blinking lights
-  **Charge**
Four lights

A2: Powering Up Your Signal Safes

Press the (blue) On/Off button once. Each unit will power up in the Charge Indicator Mode. After 3 seconds the unit will automatically move into the Signal Operation Mode.

A3: Test Your Signal Safes

Check to make sure each Signal Safe is on by holding your product upright and looking at the electronics unit. You are now ready to begin using your Signal Safes.

Section B: Product Use

Remember, there are no switches. The products work independently and change color and pattern based only on each unit's position.

B1: Stop

Either unit in the upright position produces an X.

B2: Go

Either unit in any horizontal position produces YELLOW chasing arrows.

B3: Off

Either unit held down turns all lights OFF.

B4: General Signaling Protocols

Any combination of current signals can be achieved using the Signal Safe product.

B5: Turning Off Signal Safes after Use

When you are finished using your Signal Safes, press the On/Off button once on each unit. After 5 seconds four corner lights will flash and electronics will be off. Checking the battery power after each use is recommended.

B6: Automatic Turn Off

If any unit is left ON, and in the Signal Mode, it will turn off automatically if there is no movement for 5 minutes.

QUICK START

1. Press On/Off button
2. Wait 3 seconds
product will enter the Signal Mode
3. Begin Using
Up = Stop
Horizontal = Chasing Arrows
Down = Lights Off

Section C : Modes

C1: Signal Mode

This is the default mode operating as described in Section B. To return to this mode from any other mode, point the unit downward and press the On/Off button twice (pause between presses). The product will now be in Signal Mode.

C2: Strobe Mode

The Strobe Mode creates a fast blinking light effect. With the unit turned horizontally to the left, press the On/Off button twice (pause between presses). The product will now be in the Strobe Mode and remain in the Strobe Mode, regardless of position, until another mode is selected or the unit is turned off.

CONTINUED >



C3: Flashlight Mode

To use one or both of your Signal Safes as a flashlight, position the product in the "up" position and press the On/Off button twice (pause between presses). The product will remain in the Flashlight Mode, regardless of position, until another mode is selected or the unit is turned off.

C4: Arrow Mode

The Arrow Mode produces continuously chasing yellow arrows, regardless of unit position. To enter the Arrow Mode, turn the product to the right (horizontal) and press the On/Off button twice (pause between presses). The unit will now be in the Arrow Mode where it will remain, regardless of position, until another mode is selected or the unit is turned off.

Section D : Charging your Signal Safes
(only use included charging devices)

D1: 12 Volt Vehicle Charging

Plug the included car charger into your 12 volt vehicle power plug. Using the included cable, plug the USB end into the vehicle charger, then plug the other end into the base of the electronics enclosure.

D2: 120 Volt Wall Outlet Charging

Plug the accessory wall charger into a standard 110 volt wall outlet. Using the included cable, plug the USB end into the wall charger, then plug the other end into the base of the electronics enclosure.

D3: USB Charging

Plug the smaller connector (x2) of the included cable into the base of each unit. Plug the USB end of the cable into any powered USB port.

D4: Charging Times

Charging times will vary based on the amount of charge remaining when charging begins. Typically, an 80% charge can be achieved in 20 minutes using any charging method. Approximately two hours are required to charge from 80% to 100%.

Section E: Product Contents

- E1:** Two Signal Safes (one pair) attached to straps
- E2:** One Wall Charger
- E3:** One Car Charger
- E4:** One USB charging cable with splitter
- E5:** One Storage Case

Section F: Product Identification

F1: Matching serial numbers for identification

- F1a:** Product serial numbers are located on the back of the electronics cases.
- F1b:** Case serial number is located below.



Section G: Warranty

Signal Safes are water resistant - malfunction may occur if electronics are fully submerged in a fluid.

Each product sold by Signal Corporation is fully warranted for one full year from the date of purchase. Warranty is limited to failure of any components or workmanship when the product is used as intended.

Any modification to the Signal Safe product will void the warranty and could permanently damage the product. Intentional destruction or loss are not covered by the Signal Safe Warranty.

Section H: Customer Service

- H1:** 800.920.7336 Toll Free
- H2:** 303.670.8270 Office
- H3:** support@signalgloves.com
- H4:** www.signalgloves.com
- H5:** 4602 Plettner Lane Unit 3C
Evergreen, CO 80439 USA

Section I: Product Notes

I1: Signal Safes are Patent Pending. All rights are reserved and enforced. Signal Safes are produced and assembled in the United States of America. All names, logos, and text are protected.

I2: Signal Corporation International, LLC is not liable for any injuries that may occur during use or storage of the Signal Gloves, Signal Safe, Signal Flare or Signal Paddle Products.